

## FSF12 Installation Instructions

1. Disassemble the Flange Base by removing the #10-32 x 3/4" countersunk screws. Use the Flange Base Bottom as a template to mark the holes to be drilled in the countertop.
2. Prepare (4) 5/16" holes through the countertop. The holes need to be aligned with the 4" x 2-1/2" bolt pattern on the Flange Base Bottom.
3. If the monitor or electrical cords will be run through the tube, prepare a hole centered with the Flange Base and large enough to clear the cords used. The maximum diameter is 1-1/4".
4. Attach the Flange Base Bottom to the countertop with the provided 1/4-20 x 2-1/2" screws, flat washers and hex nuts. Tighten the hex nuts to ensure the base will not move.
5. Place the Flange Base Top on the bottom but do not secure the screws until after the tubing is attached.
6. Apply two drops of Thread Locking Agent to the pipe threads on the tubing and screw into the coupling in the Flange Base. Use a strap wrench to tighten the tubing without damaging the finish on the tubing.
7. Lift up the Flange Base Top to expose the coupling in the bottom. Screw in the provided 1/4-20 x 3/8" set screw to ensure the pipe can not be unscrewed by swiveling the screen.
8. Attach the Flange Base Top to the bottom with the #10-32 x 3/4" countersunk screws.



