

PROGRAMMING AND OPERATING INSTRUCTIONS
for the
PDI-Z9TV-C Through G Models

The instructions assume you have installed the television and are supplying correct voltage and a nominal CATV signal level of 15 to 10 dbmv. All channel and picture adjustments are accomplished through the use of an infrared remote control. Use the PDI model PDI108-206 for basic programming (use the model PDI106-209 for bank (tier) programming). The Z9TV television provides 4 individual memory banks (tiers) for channel programming. In other words, 4 different sets of channels can be programmed into the television. Once programmed the channel banks (tiers) are selected by a remote control with a **BANK** button.

TO PROGRAM CHANNELS INTO THE Z9TV-C Thru G

- Step 1.** Turn the **TV ON**. You should notice a visible raster or picture on the television screen. If the set appears dead, verify correct power supply voltage to the television. Note a front mounted red power light glows brightly when the television is powered **ON**.
- Step 2.** Press the remote controls **MENU** button. Press the **SELCT** button to advance the cursor through the **MENU**. Choose **AUTO CH. SEARCH**.
- Step 3.** Press **ADJUST** to start the search. The television will now search through all available channels and place active channels into each of the television's memory banks. **IMPORTANT- AUTO CH. SEARCH ALWAYS** overwrites each of the channel memory banks making each bank identical.
- Step 4.** To edit individual channel banks, select the desired bank. Press the remote control's **BANK** button once to display the current channel bank. Press **BANK** a second time to advance to the next channel bank.
- Step 5.** Press the remote control's **MENU** button. The **SETUP MENU** will appear. Press the **SELECT** button to advance the cursor through the menu. Choose **CH. ADD/DEL** with the **ADJUST** button. Press **CHANNEL** up/down to advance through current memory to the offending channel. Press the **ADJUST** button to delete the offending channel.
- Step 6.** In a similar manner, channels can be added. Enter the **CH. ADD/DEL** menu. Press the **SELECT** button advances down through every channel and should be used to add a channel not originally programmed via **AUTO CH. SEARCH**. You can also manually enter the channel number to be added.

PROGRAMMING THE PD108-206 REMOTE CONTROL

If the TV does not respond to the remote control, you must program the universal remote to generate IR signals that control the PDI hospital TV.

- 1.** Manually turn **ON** the TV you would like to control.
- 2.** Press and hold down the **CODE SEARCH** button on the remote until the remote's LED lights.
- 3.** Press and release the TV button on the remote. The remote's LED light will blink and then remain lit.
- 4.** Enter the 3-digit code **405** on the remote's number keypad. If properly entered, the LED will turn off. If the LED blinked rapidly when you entered the code you may have entered an invalid code.
- 5.** Now, verify that the remote controls the TV.